

Care Instructions

Cleaning the Acoustic Felt & Wood

DAILY CLEANING

01 / Washing

Acoustic felt: Gently remove dust and loose dirt using a vacuum cleaner with a soft-bristle attachment. If necessary, the surface can be gently cleaned with a slightly damp, soft cloth. Avoid getting the felt wet or scrubbing it hard.

Wood: Wipe the surface with a soft, dry, or slightly damp cloth. If necessary, use a mild cleaning agent that is suitable for the surface finish. Wipe dry with a clean cloth and avoid leaving moisture on the wood surface.

Important: Do not use abrasive cleaning tools or strong cleaning agents. Avoid using large amounts of water, as this can damage both the acoustic foam and the wood.

02 / Maintenance of Wooden Slats

Wooden slats that have been oiled from the start may need to be re-oiled as needed to preserve the wood's appearance and protective finish. How often maintenance is needed depends on the type of wood, the finish, and how the product is used. Use a wood oil that is suitable for the specific wood surface. Make sure the surface is clean and dry before treatment.

03 / Stains and Spills

Remove spills and stains as soon as possible to reduce the risk of permanent discoloration. Gently blot up the liquid with a clean, dry cloth without rubbing. Follow the cleaning instructions for the respective material when continuing to clean.

Note: Use only cleaning agents and maintenance products that are suitable for the respective materials and surface finishes. If necessary, test on an inconspicuous area first. Avoid getting the acoustic felt wet or leaving moisture on the wooden surface.